



BILLET BOY TOMBSTONE LED CIRCUIT BOARD

INSTALLATION INSTRUCTIONS

NOTE: If you are not familiar with or adept at performing any of the following procedures, we strongly suggest that you have this item installed by a professional technician.

1. Remove rear wheel.
2. Remove rubber boot covering the back of the taillight assembly.
3. Unhook wiring connectors from the taillight.
4. Remove the three nuts holding the taillight assembly to the fender.
5. Disassemble the taillight unit by removing the three button head allen screws from the face of the unit.
6. Drill out the brass rivet holding the stock bulb sockets to the grey plastic piece. Remove the bulb sockets and wiring.
7. Cut the wires from the bulb sockets and splice them to the wires from the led circuit board: Red to red, black to black, and blue to green. Cut the grey wire to the plate light and terminate it with shrink tubing on the end. This wire has power when the ignition is on so make sure it doesn't contact any part of the taillight or fender. Now would be a good time to turn on the lights and apply the brake to make sure everything works correctly.
8. Slide the circuit board in between the red lens and the clear lens, attach the grey plastic piece with the three button head allen screws, adjust the wiring to run up toward the grommet in the fender taking care not to pinch it anywhere, and reinstall the assembly on the fender.
9. Reinstall the rear wheel and go riding.